

Removal of Soap Scum & Hard Water Deposits/Mildew Stains

Purpose: To remove water deposits, mildew and soap scum on tile and acid-resistant stone surfaces.

Method

Product: Aqua Mix **Shower Tile Cleaner** (Note A, B & C) or Aqua Mix **Phosphoric Acid Cleaner**.

Equipment: **AquaBug Cleaning Kit**, white nylon scrub brush or scrub pad.

Coverage: Varies depending on use and amount of buildup.

Procedure:

1. Always test a small area first to ensure satisfactory results.
2. Apply pre-diluted solution of Aqua Mix **Shower Tile Cleaner** to surface.
3. Agitate with **AquaBug Cleaning Kit**, white nylon scrub brush or scrub pad.
4. For stubborn areas, allow to dwell 5 to 10 minutes before agitating.
5. Rinse thoroughly with clean water.

Note A: Do not use on polished marble, limestone or on other acid-sensitive tile or stone.

Note B: For areas with stubborn or heavy buildup, **Phosphoric Acid Cleaner** is recommended in place of **Shower Tile Cleaner**, used per product directions.

Note C: For removal of soap scum and mildew stains on acid-sensitive surfaces, **Heavy-Duty Tile & Grout Cleaner**, **Grout Deep Clean** or **Stone Deep Clean** is recommended.

Technical Assistance:

1. Call +61 2 9521 4000
2. Visit our web site www.aquamix.com.au
3. Email all technical questions to technical@aquamix.com.au

These recommendations are intended as general guidelines for the removal of soap scum/mildew stains/hard water deposits. The actual removal requirements may vary depending on the use and amount of mildew and/or soap scum to be removed.

Read product directions thoroughly prior to use. Always test first.

Keep surface clean and dry to reduce possibility of slip-fall accidents.