

Repolishing (Wet Process) Calcium Based Stones – Marble, Limestone, Travertine & Cement Terrazzo

Purpose: To repolish and or maintain polished calcium-based stones (WET PROCESS).

Method

Product: Aqua Mix **Reviver** (Notes A & B).

Equipment: Low RPM (175 – 300) floor machine utilizing red, natural hair or synthetic, tan and fiber floor pad.

Procedure:

1. Always test a small area first to ensure satisfactory results. Mix well before using.
2. Ensure surface is clean and free of existing coatings.
3. Protect baseboards, carpet, etc. with protective plastic and/or blue painter's tape.
4. Wet area no larger than 2 m² with water and place 2 tablespoons of Aqua Mix **Reviver** in the center.
5. Using a red, natural hair or synthetic, tan, fiber floor pad work the area in a side-to-side motion with a 175 – 300 RPM floor machine.
6. Continue until desired polish has been achieved. Squeegee slurry from a small area to check for desired results prior to removing all of the slurry mixture off of the floor.
7. Pick up solution with a wet/dry vacuum and rinse thoroughly with clean water.
8. Polish dry with a new polishing pad or cotton bonnet.

Note A: Severely damaged or worn polished stone may require professional restoration.

Note B: Not recommended for use on green marble.

Technical Assistance:

1. Call +61 2 9521 4000
2. Visit our web site www.aquamix.com.au
3. Email all technical questions to technical@aquamix.com.au

This recommendation is intended as a general guideline for repolishing and maintaining worn calcium based stones (marble, Limestone, travertine or cement terrazzo). The actual polishing requirements may vary depending on type of stone, method of application and condition of the stone to be polished.

Read product directions thoroughly prior to use.

Always test first. Keep surface clean and dry to reduce possibility of slip-fall accidents.